


POST MEASUREMENT CHART: HARBOR POST CAP



MEASUREMENT DIRECTIONS
 Measure the actual width of your post and order according to the post size chart.

SKU	POST SIZE (A)	OPENING SIZE (B)	OVERALL WIDTH (C)	OVERALL HEIGHT (D)	BLOCK HEIGHT (E)	MOLDING DEPTH (F)
) C312	3-1/2"	3-5/8"	5"	3-1/8"	1- /"	1-/8"
) C312512	3-1/2" x 5-1/2"	3- / " x 5-5/8"	5-"x7-"	3-1/8"		1-/8"
) C334	3-3/4"	3-7/8"	"			1-/8"
) C4	4"	4-1/8"				1-/8"
) C46	4"x6"	4-1/8"x6-1/8"	6"x8"			1-/8"
12	4-1/2"	4-5/8"	6-3/4"			1-/8"
) C434	4-3/4"	4-7/8"	7 "			1-/8"
5	5"	5-1/8"	7 "			1-/8"
12	5-1/2"	5-5/8"	7-3/4"			1-/8"
534	5-3/4"	5-7/8"	8"			1-/8"
) C6	6"	6-1/8"	8"			1-/8"
) C612	6-1/2"	6-5/8"	8-3/4"			1-/8"
) C7	7"	7-1/8"	9-1/4"			1-/8"
) C712	7-1/2"	7-5/8"	9-3/4"			1-/8"
) C8	8"	8-1/8"	10-1/4"			1-/8"
12	8-1/2"	8-5/8"	10-3/4"			1-/8"
) 8	9"	9-1/8"	11-1/4"		2- "	1- 8"
) C912	9-1/2"	9-5/8"	11-3/4"			1-/8"
) C10	10"	10-1/8"	12-1/4"			1-/8"